

















TIPS

Before using, please study this manual and keep it for future reference or go to www.Boompods.com for further details.

Make sure you choose the best fitting silcone tips and wings, this will deliver better sound and secure fitting.

Please charge fully before first use.

If they are left unused for over 2 weeks, please recharge.

If your phone cannot find the earbuds try switching the Bluetooth Off /On on

If the case runs low on battery the earphones will not auto switch On or Off.

If left unconnected for long periods you may need to disconnect from your phone and start the original pairing procedure.

Please only use good quality (recognised brand) power source to charge from.

Download "Boomtune" from App Store or Google Play store, this App will give you the ability to adjust sound EQ and reconfigure the controls. Please Note: Android users, once App is downloaded pointing is automatic whist using the App, but Apple users will need to pair via the original pairing method then replace into the case and remove to active the App feutures.

COLOUR

FCC STATEMENT

RDR-IN1950

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must acceptany interference received, including interference that may cause undersired

Changes or modifications not expressly approved by the party reponsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digitaldevice, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonableprotection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications However, there is no guarantee that interference will not occur in a particular installation. if this, equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connect. Consult the deeler or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement, the device canbe used in portable exposure condition without restriction.

Boombuds GS Stand time: Music time: 4.5hr Charging time: Talking time: Operation range: 10m(with no obstacle) Battery type: Battery capacity(earbud): 3.7V, 43mAh Battery capacity(case): 3.7V, 300mAh Input parameter(case): Bluetooth profiles: 5V===400mA HSP/HFP/A2DP/AVRCP

